

141	142	143
144	145	146
DMX 20	NET15	D1

S.R GALLEY MULTI PANEL(5)

129	130	131
132	133	134
DMX 18	NET13	D1

S.R GALLEY MULTI PANEL(4)

117	118	119
120	121	122
DMX 16	NET11	D1

S.R GALLEY MULTI PANEL(3)

105	106	107
108	109	110
DMX 14	NET9	D1

S.R GALLEY MULTI PANEL(2)

93	94	95
96	97	98
DMX 12	NET7	D1

S.R GALLEY MULTI PANEL(1)

225	226	227
DMX 33	NET25	

REAR MULTI PANEL

228	229	230
DMX 34	NET26	

REAR MULTI PANEL

271	272	273	274
275	276	277	278
DMX 43	NET29		

3. STAGE WALL BOX

213	214	215	216	217	218	219	220	221	222	223	224
DMX 32	NET24			DMX 32			DMX 31				DMX 31

REAR

279	280	281	282
283	284	285	286
DMX 44	NET30		

4. STAGE WALL BOX

147	148	149
150	151	152
DMX 21	NET16	D2

S.L GALLEY MULTI PANEL(5)

251	252
DMX 39	

S.R FLOOR POCKET(5)

77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92
DMX 11	NET6				DMX 11					DMX 10					DMX 10

UPPER

253	254
DMX 40	

S.L FLOOR POCKET(5)

247	248
DMX 39	

S.R FLOOR POCKET(4)

61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76
DMX 9	NET5				DMX 9					DMX 8					DMX 8

4. SUS

249	250
DMX 40	

S.L FLOOR POCKET(4)

243	244
DMX 39	

S.R FLOOR POCKET(3)

45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
DMX 7	NET4				DMX 7					DMX 6					DMX 6

3. SUS

245	246
DMX 40	

S.L FLOOR POCKET(3)

239	240
DMX 37	

S.R FLOOR POCKET(2)

29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44
DMX 5	NET3				DMX 5					DMX 4					DMX 4

2. SUS

241	242
DMX 38	

S.L FLOOR POCKET(2)

235	236
DMX37	

S.R FLOOR POCKET(1)

13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
DMX 3	NET2				DMX 3					DMX 2					DMX 2

1. SUS

237	238
DMX 38	

S.L FLOOR POCKET(1)

255	256	257	258
259	260	261	262
DMX 41	NET27		

1. STAGE WALL BOX

231	232
DMX 35	

ORCHESTRA PIT

233	234
DMX 36	

ORCHESTRA PIT

263	264	265	266
267	268	269	270
DMX 42	NET28		

2. STAGE WALL BOX

1	2	3	4	5	6	7	8	9	10	11	12
NET1											DMX 1

GRID

191	192
193	194
195	196
DMX 28	NET21

FRONT SIDE

207	208
DMX 29	NET22

BALCONY WALL BOX

203	204
DMX 29	NET22

BALCONY WALL BOX

209	210
DMX 30	NET23

BALCONY WALL BOX

205	206
DMX 30	NET23

BALCONY WALL BOX

211	212
DMX 28	NET21

BALCONY WALL BOX

197	198
199	200
201	202
DMX 28	NET21

FRONT SIDE

153	154	155	156	157	158	159	160	161	162	163	164	165	166	167	168
DMX 22	NET17				DMX 22					DMX 23					DMX 23

1. CEILING

169	170	171	172	173	174	175	176	177	178	179	180	181	182	183	184
DMX 24	NET18				DMX 24					DMX 25					DMX 25

2. CEILING

185	186	187	188	189	190
D3	NET19				DMX 26

3. CEILING(FOLLOW PIN ROOM)

\*NOTE\*

D43 : Dimmer Circuit ※1,2 PARALLEL TYPE

DMX 1 : DMX Circuit (Spin Type)

NET1 : Network Circuit

D1 : Direct Circuit



제천예술의전당

제천예술의전당 대공연장 무대조명 회로 배치도